




Measuring the Interface Traction during Peel Test of Adhesive Tapes




Motivation



Theory



Methodology



Displacement
(X, Y, Z)



Strain
(X, Y, Z)




Stress 2D-Field
(F_T & F_N)




Interface
Traction (F_N)



Experimental Setup



Confocal Microscope Results




$1000\mu m \times 1000\mu m \times 100\mu m$
 $x \quad y \quad z$




University of Colorado **Boulder**

Confocal Microscope Results




Confocal Microscope Results



Data Processing

Tracer Particle Displacement Methods


- IMARIS
- Traction Force Microscopy (TFM)



Peel Front Displacement Field

Force acting on surface of infinite half-space


- **Boussinesq–Cerruti solution (3D)**
- **Flamant solution (2D)**



Data Processing

Tracer Particle Displacement Methods


- IMARIS
- Traction Force Microscopy (TFM)



Peel Front Displacement Field

Force acting on surface of infinite half-space

- **Boussinesq–Cerruti solution (3D)**
- **Flamant solution (2D)**



Red Channel (2D) – Rhodamine- β



Image manipulation





Image manipulation




Method 2: Peel Front Displacement Field

Boussinesq-Cerruti solution

$$u_z(x, y=0, z) = -\frac{3}{4\pi E} \int_{-b/2}^{b/2} \int_{a_1}^{a_2} \sigma(x') \frac{2z^2 + y'^2 + (x-x')^2}{\left[(x-x')^2 + y'^2 + z^2\right]^{3/2}} + \tau(x') \frac{(x-x')z}{\left[(x-x')^2 + y'^2 + z^2\right]^{3/2}} dx' dy'$$

Flamant solution

$$\frac{\partial \bar{u}_z}{\partial \bar{x}} = -\frac{2(1-\nu^2)}{\pi E} \int_a^b \frac{p(\bar{s})}{\bar{x} - \bar{s}} ds + \frac{(1-2\nu)(1+\nu)}{E} q(x)$$



Method 2: Peel Front Displacement Field

Boussinesq-Cerruti solution – Symmetric about b (width)

$$u_z(x, y=0, z) = -\frac{3}{4\pi E} \int_{-b/2}^{b/2} \int_{a_1}^{a_2} \sigma(x') \frac{2z^2 + y'^2 + (x-x')^2}{[(x-x')^2 + y'^2 + z^2]^{3/2}} + \tau(x') \frac{(x-x')z}{[(x-x')^2 + y'^2 + z^2]^{3/2}} dx' dy'$$

Flamant solution – Plain strain condition

$$\frac{\partial \bar{u}_z}{\partial \bar{x}} = -\frac{2(1-\nu^2)}{\pi E} \int_a^b \frac{p(\bar{s})}{\bar{x} - \bar{s}} ds + \frac{(1-2\nu)(1+\nu)}{E} q(x)$$

Assumption: No tangential forces for both solutions



Flamant solution – Simple form

$$\frac{\partial \overline{u_z}}{\partial \bar{x}} = -\frac{2(1-\nu^2)}{\pi E} \int_a^b \frac{p(\bar{s})}{\bar{x} - \bar{s}} d\bar{s}$$

$$f(\bar{x})$$



Evaluated from
experiment data

=

$$-c$$



Constant
(Material dep.)

$$\int_{s=0}^{s=1} \frac{p(\bar{s})}{\bar{x} - \bar{s}} d\bar{s}$$



Integrate and
solve for $p(s)$

Methods to solve:

- Discretize and solve the system of equations
- Laplace Transform



Flamant solution – Discretization

$$\frac{\partial \overline{u_z}}{\partial \bar{x}} = -\frac{2(1-\nu^2)}{\pi E} \int_a^b \frac{p(\bar{s})}{\bar{x} - \bar{s}} ds$$

$$f(\bar{x}) = -c \int_{s=0}^{s=1} \frac{p(\bar{s})}{\bar{x} - \bar{s}} ds$$

$$b = A x$$

$$\begin{bmatrix} f(x_1) \\ \vdots \\ f(x_N) \end{bmatrix} = \begin{bmatrix} (x_1, s_1) & \cdots & (x_1, s_N) \\ \vdots & \ddots & \vdots \\ (x_N, s_1) & \cdots & (x_N, s_N) \end{bmatrix} \times \begin{bmatrix} p(s_1) \\ \vdots \\ p(s_N) \end{bmatrix}$$


$$x = A^{-1}b$$



Results – “test” displacement scenarios


Legend:

--- : Input displacement
--- : Calc. force




Next Steps:


- Verify code again
- Implement boundary conditions
- Verify results using ABAQUS or other simulation software
- More testing (with more nodes)
- Apply method to experiment values




Method 1: Tracer Particle Method



Results




Results




25th Timepoint – ux


Red channel Image



IMARIS Quiver Plot




Interpolation Result




25th Timepoint – ux


Red channel Image





IMARIS Quiver Plot



Interpolation Result




25th Timepoint – ux



- Current grid size : 950X3550X100



Next Steps?



Acknowledgements

- **Advisor:**
 - Dr. Rong Long
- **Non-Linear Mechanics Lab (NML):**
 - Salil Rabade (PhD candidate)
 - Guillaume Lostec (PhD candidate)
- **3M:**
 - Dr. Michael Wald
 - Dr. Ryan Birringer
 - Dr. Jonathan Kemling
 - Dr. Dylan Cosgrove
- **Equipment:**
 - BioFrontiers Institute
 - Joe Dragavon
 - Rentschler Research Group

